

# INT420 Colorflash softbox 60 x 60cm (24inch)

INTERfit

## ASSEMBLY INSTRUCTIONS

### Parts list:

Qty	Description.
1	Connector ring
4	Frame rods
1	Outer cover
1	Internal diffuser 43 x 43cm (17 x 17ins)
1	Outer diffuser 60 x 60 cm (24 x 24ins)

To assemble the Softbox;

Take the outer cover and open the Velcro flaps on the rear edge to allow for easy assembly. Check that the four frame rods are still threaded through the two guide loops found on the inside corners of the cover. (See picture).



Now take the metal connecting ring and fix one frame rod at a time tensioning them between the location holes in the outer rim of the connector ring and the pockets on each corner of the outside edge of the main cover. It is easier to fix the frame rods that are opposite to each other, so that each rod remains tensioned after it is fixed in place.



The internal diffuser can now be fixed into place on to the 4 elastic tabs, which can be found half way down the inside face of the cover.

The main outer diffuser can now be fixed in place using the Velcro pads found on the outer edges of the cover.

Close the Velcro flaps on the rear of the outer cover and the Softbox is ready to be fitted onto the flash unit.



Loosen the three reflector fixing nuts and remove the metal 'spill kill' reflector from the flash unit, clip the softbox connector ring onto the three fixing nuts, tightening them up to ensure that the softbox is firmly fixed in place.

For Further instructions please contact

Interfit Photographic Limited  
Unit 4 Cleton Business Park  
Cleton Street  
Tipton  
West Midlands  
DY4 7TR  
UK  
Telephone: +44 121 522 4800  
Fax: +44 121 557 2221